

EVO15.0 280-868Mhz Universal Remote Control Duplicator

Multi frequency rolling code remote Control duplicator user manual

Features:
1 for all
Multi-frequency & auto scan
Easy duplicating
Patent right reserved

Duplicating procedures:

BEST POSITION FOR THE
DUPLICATION



Programming

FIXED CODE DUPLICATING PROCEDURES

- 1) While pressing the button 1, press 4 times the button 2.
- 2) Release both buttons. Now the led of the EVO15.0 emits a quick flash every 2 sec.
- 3) Place the original remote control in front of the "EVO15.0", at about 4-60 cm of distance (as shown in the picture above).
- 4) Press and retain pressed the button of the original remote control that you want to copy until the EVO15.0's LED will change frequency of flashing (faster than before), as a confirmation of the correct copy of the code.
- 5) While the LED is flashing, press the button of the "EVO15.0" where you want to store the code just copied, until the led turn off.
- 6) The copy has been applied with success. Verify on the automation the orderly functioning of the new remote control.

ROLLING DUPLICATING PROCEDURES

- 1) While pressing the button 1 of the "EVO15.0", press 4 times the button 2. Release both buttons. Now the LED of the WHY emits a quick flash every 2 sec.
- 2) Place the original remote control in front of the "EVO15.0", at about 4-60 cm of distance.
- 3) Press and retain pressed the button of the original remote control that you want to copy until the EVO15.0's led will turn on with a light and then emits a double flash every 2 sec.
- 3) Transmit now the seed code of the original remote control (by pressing the rear hide button or the buttons 1 and 2 simultaneously in the new models)
- 4) Now the LED will flash quickly, press the button of the "EVO15.0" where you want to store the code just copied, until the LED will turn off.
- 5) Now activate the procedure to insert the new remote control on the receiver.

BFT

1. While pressing the button 1 of the "EVO15.0", at the same time press 4 times the 2 button.
2. Release both buttons. Now the EVO15.0 LED will emit a short flash every 2 seconds.
3. Place the original remote control to be programmed in front of the "EVO15.0", at about 4-60 cm of distance
4. Press and retain pressed the button to be programmed of the original remote control, till the LED will switch on as a fix light; now release the button.
5. The EVO15.0 LED will emit a short flash every 2 seconds.
6. Transmit now the SEED CODE of the BFT original remote control, press the hidden buttons until the original remote control LED switches on.
7. Now the EVO15.0 LED will change the flash mode (more fast), for a reconfirmation of the correct code learning. This step may take some seconds.
8. At this moment, press the new remote button when you want to store the code and retain pressed until the EVO15.0 LED switches off
9. Activate now the procedure to insert the new remote control on the receiver.

Compatible List

Brand	Model	Brand	Model
ACM (AMC)	TX2, TX2 COLOR, TX4	KEY	900TXB-42R, SUB44, TXB-44R, TXG-44R
ADYX	TE4433H BLUE, 433-HG BRAVO	KINGGATES	STYLO, CLIPPER
AERF	COMPACT, HY-DOM, MERCURI B, MERCURI C, SABUTON, MARS, SATURN, ST3/N, TERRA, TMP-1, TMP-2, UNITECH	KUING	KUA, KUAE, KUA S
ALLMATIC (AMC)	BROWN, BROWN RED, BRO.OVER, PASS, MINIFACE, TECH3, FORA	LABEL	SPYCO, RIJW4E
APERIO	GO, GO PRO, GO MINI	LEB	TMW
APERTO (SOMMER)	TXD2-434-2, TXD2-858-2 BLUE, 4025 TXD2-868-2, 4022 TXD2-434-2, 4020 TXD3-434, TX-Q3-868-4, 4013, TXD3-434-4	LINCE	LR2035
APRIMATIC (AMC)	TR2/TR4, TM4, TXM	LIFE	LIFE FID2 / FIDO4 / VIP2 / VIP4 / VIP2R / VIP4R / STAR2 / STAR4 / BRAVO2 / BRAVO4
ATA	PTX4 BLUEM PTX4 PINK	LINEAR	MCT-11, ACT-22, ACT-21, STING RAY ACT-31, STING RAY ACT-34B
AVIDSEN	104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250, TX4 114253	MHOUSE (AMC)	GTX4, GTX4C, TX4
		MA	TX1, TX2, TX3
		MOOVO (AMC)	MT4G

Advantages

EVO15.0 is the a 280-868mhz universal remote control that replaces 4 different remotes(based on fixed or rolling code)

1) Advantages of V15.0 Versions

1. Can clone more brands (updated 50 more brands)
2. Longer copy distance (Old: 4-5cm, V15.0 max: 50-60cm, easier to copy the remote with weaker signal)
3. Longer control distance.
4. No battery problem.

Auto Matching Code

1) First of all you must be close to the automation.

2) Press and retain pressed the programmed button for about 10 sec, when the LED start to flash, release the button.

3) Wait until the LED will turn off. The operation has been done, now you can use your new remote control

To activate on the receiver all the other models: Refer you to the instructions of the original model.

NOTE: THE SEED CODE OF THE EVO15.0 CAN BE EMITTED AS HERE BELOW:

1. Press the buttons 1 and 2 simultaneously for 8 seconds and release them when the LED start to flash;
2. While the LED is flashing press the button with the seed code needed.

FAAC /GENIUS (FAAC SLH 433-868/ GENIUS 868)

ATTENTION, PLEASE: Verify that the remote control is a MASTER. Pressing any buttons, the LED should issue a double flash rather than switch on as a fixed light.

1) While pressing the button 1 of the "EVO15.0", press 4 times the button 2. Release both buttons. Now the LED of the WHY emits a quick flash every 2 sec.

2) Predispose the FAAC remote control for the emission of the seed code (by pressing simultaneously the buttons 2 and 3)

3) While the FAAC LED is flashing, place it in front of the "EVO15.0", at about 4-60 cm of distance and press the button that you want to copy until the EVO15.0's led will change frequency of flashing (faster than before), as a confirmation of the correct copy of the code.

4) While the LED is flashing, press the button of the "EVO15.0" where you want to store the code just copied, until the led will turn off.

V2

1) Press and hold button 1 and press button 2 four times at same time, Release 2 buttons till LED flashed once every three seconds

2) Put original remote in the front of new remote (about 4-60cm), press and hold the original remote button which need to be copied until the LED will turn on with a fixed light and then emits a double flash very 2 seconds

3) Press and hold once again the same button of original remote, the LED of new remote will flashes quickly, press the button that you want to save the code, until the LED off

4) Now active the remote with AMC procedure

BALLAN	FM400, FM400E, FM404B, 4013	MARANTEC	D101,D12,DIGITAL302,DIGITAL304
BENINCA (AMC)	TO.GO.WV, TWV, ROLLKEY, APPLE LOT WCV, CUPIDO, TO.GO.QV, IO, LOT2WCV, LOT1W, LOT2W, LOT4W, LOT1WM, LOT2WM, T2W, T4W, HAPPY VA, IO, TO.GO.VA	MERLIN + /Gifco	M230T(PROLIFT), MA30R(PROLIFT), C943, C940, C943, CMB42, CMB44
		MERLIN 2.0	E945M, E943M, E940M
BESIDE	BEZAP, HIT	MONSIEUR	ARC
BFT (AMC)	MITTO, MITTO M(MITTO 2M/MITTO4M), MITTO RCB(MITTO RCB02/MITTO RCB04), MITTOA(MITTO 2A/MITTO 4A), MITTO B, TRC(TRC2/TRC4), GHIBLI, MURALE, KLEO, TEO1, TEO2, TEO4, RB4 MURALE	NORMSTHAL	RCU 2/4 K, EA433 2/4 K
		NICE	SMILO, FLOR-S, VERY-VR, FLOR-S ERA, ONE (ON), ON ERA, INTI, ERGO, PLANO, ONE (ON FM)
CAME	T431, T434, TOP432A, TOP434, TOP432, TAM432SA, TOP432NA	NORTON	NEO, TXCD, GO NORTON, GO MINI NORTON
CARDIN (AMC)	TRQ 5449, TRQ 5449 GREEN (PRECODE), TXQ 5449, TXQ 5449 GREEN, TRQ 5486, TXQ 5486, 5437 TX, XRADO	NOVOTECNICA (AMC)	BLXL2
		NOVOFORM	MCHS, MICRO-NOVOTRON 502, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS, MINI NOVOTRON 522
CASALI	JA33 AMIBO, GENIUS/CASALI A252RC		
CASIT	ERTS92B, ERTS92T, ERTS476D, ERTS200Q, ERTS476D, ERTS476Q	NOLOGO	ECO DIP
CELISA	510 1, 510 2	O&O (AMC)	TX, T.BOM, TWIN, TX, TWIN, TX2/TX4, TX(NEO)
CENTURION	CLASSIC, SMART	O&G	OG62, OG64
CHAMBERLIN/ LIFTMASTER/ MOTORLIFT	953ESTD, 371 LM, 971LM, 84330E, 94334CE, 94333E/94335E, 9747E, 1A5639-7, 1A5477, 1A6407, 15202372, 94330EM-L/94335EM-L/94333EML, 94330EM-L/94333EML/94335EML, 8747EML	OPENOUT	TMQ
		PECCININ	TX MENBRANA
		PORTAMATIC	MPH01, MPH02
CLEMISA	MUTANCODE, T, T-B, E-CODE N, MASTERCODE MV	PRATEL	MTE, MPSTLE, MPSTP2E, TCE, BEOR, TRQ-P, SLIM-E
CPS	TCP3, CPS1, CPS2, CPS4	PROEM	ER4C4ACS
DASPI (AMC)	HAPPY2, POPS 2, ZERO RC(ZERO 2RC, 4RC)	PROGET	ETY_433N2, ETY_433N4
DEA	PUNTO 278, GOLDR, GENIE R 273, GENIE R-GT2M, MIO TR, GT2M, TRN	PROTECO	TX433, EUROMATIC
DELMA	MIXARD 433 1, MIXARD 433 2, KING 433 2	PUJOL	TWIN, VARIO, VARIO MARS, VARIO OCEAN, NEO
DICKERT	MAH5433 01, MAH5433 04	QUASAR	433
DITEC/ENTREMATC (AMC)	GOL, GOL4C, BXL52, BXL2P, BIXAG4, BXL6, ZEN	RIB	LITHLO
DOORMATIC	SAW, MILENY, MILENY-EVO	ROPER	NEO, GO ROPER, GO MINI ROPER
DOITRAND	MPSTF2E, JAUNE	SABUTOM	BROOVER, BROSTAR
DOORHAN	TRANSMITTER 4	SEA	HEAD, SMART DUAL ROLL, SMART-3 ROLLING CODE, COCCOMELLA ROLL
DUCATI	TSAW1, TSAW2, TSAW3, 124, TE2	SECULUX	NEO
ECOSTAR	R5E, R5C, R5Z	SEAV	BE HAPPY RS(BE-HAPPY-RS1, BE-HAPPY-RS2, BE-HAPPY-RS3), BE-SMART RSX, BE-HAPPY RH1, BE-HAPPY RH2, BE-HAPPY RH3, BE SMART
ELBE	501, 502, 504, 502A, 504A		
ERREKA	IRIS, ROLLER 2, ROLLER 433, ROLLER 868, SOL433, SOL868, VEGA 433, VEGA 868	SILVELOX	MH2 2007, QUARZ SAW
ELCA	IRIS, ASTER, ASTER 1000, ASTER 1001	SKE	4790207
FAAC (AMC)	XT 433 RC, TM1 433 DS, TM2 433 DS, TM3 433 DS, 433L2, 433L4, TM2 433 SLP, TM4 433 SLP, TLM 433SLH, TLM 868SLH, DL 868SLH, XT 868SHL, XT 433SHL, T 868SHL, T 433SHL, XT433RC, TE433HG	SIMINOR	CVXNL, MITTO, SIM433
		SECURVERA	SV R2C, SV R4C, SV R6C
FADINI (AMC)	FADINI JUBI, JUBI SMALL, ASTRO 433 SMALL, 433 M2 ASTRO 433-2, ASTRO 433-4, JUBI2/JUBH, JUBI 433, DIVO 71/4	SERAJ	OG/52, OG54, OG82, OG84, OG/28, OG48, OG62, OG84
FERPORT	TAC1, TAC2, TAC4, TAC 1K, TAC 2K, TAC 4K, TAC2KR	SOMFY	LEIS, K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA
GIBIDI	GIBIDI OPEN TMB, OPEN OUT, AU1590, AU1600, DOMI- NO AU1680 WOOD, GIBIDI AU1610, GIBIDI AU1680, AU1810, AU03000, AU03000 DOMINO, DTC 4334, DTS4334, AU0400, MAXO	SOMMER	SOMMER 4026 TX03-868-2, SOMMER 4020 TX03-868-4, SOMMER 4031, SOMMER 4025, SOMMER 4011, SOMMER 4035, APERTO 4025
GULLIVER	MDW	STAGNOLI	KALLISTO, VENUS AV223
GENIUS (AMC)	AMIGO, AMIGOLD, KILO, BRAVO, ECHO	TAU (AMC)	250K-SLIMRP, 250K-SLIMR, 250T-4RP
GENIE (AMC)	GTR-3, GIT, GICT390, GIFT390-1, G3T-BX, G1T-BX, GM3T, GICTD, GIFTD	TELCOMA	FM402, FM402E, FM400E, FM400
HORMANN	HSM2, HSM4	TORLIFT	TORMIT4
JCM	NEO, TWIN, GO, GO PORTIS, GO NORTON, GO MINI	VDS (AMC)	TRQ P, ECO-R
JAY	UBET X 15L1, UBET 21, UBET 41, UBET 61	VARWIFORD	EA433 4K, SMART2, SMART3
KBLUE	ETH-TEL01	V2 (AMC)	V2 PHOX 2, V2 PHOX 4, V2 PHOENIX 2, V2 PHOENIX 4, V2 TXC, V2 TRC, V2 TSC4, V2 HAND, PHOENIX 868, PHOX 868