Smart Instructions

- 1. Press the Code Button for 2 seconds and then release (the code button is located on the motor panel). The screen on the motor will show code learn.
- 2. Press the same button on the new remote twice.
- 3. Test the new remote.
- 4. If you have more than one new remote, please repeat steps 1-3.



SCAN ME



www.mtmwarehouse.com.au

Smart Instructions

- 1. Press the Code Button for 2 seconds and then release (the code button is located on the motor panel). The screen on the motor will show code learn.
- 2. Press the same button on the new remote twice.
- 3. Test the new remote.
- 4. If you have more than one new remote, please repeat steps 1-3.



SCAN ME



www.mtmwarehouse.com.au